




P.O. Box 1719
 Corona, CA 92878
 Support: 877-512-8111
 www.aFefilters.com

Intake Kit Installation Instructions: Ford F-150 (V8-4.6L)

Kit Part #	54-11122	Tools Required:	Part List:	2 Screw Hex head 1/4-20x1.25
Make:	Ford	5/16" nut driver	1 Air filter part # 24-90039	2 Washer 1/4"
Model:	F150	10mm socket	1 Housing powder coat black wrinkle	1 Trim seal (18.5")
Years	2006	Flathead screwdriver	1 Intake tube rotomolded	2 Clamps #052
Engine	V8-4.6L	Ratchet and extension	1 Adapter, injection molded	2 Clamps #060
			1 Gasket tube flange	2 Clamps mini #012
			4 M6 x 1 x 20mm hex head	2 Clamps mini #008
			2 Spacer nylon	1 Grommet temp sensor
			1 Coupler 3" x 3"	1 hose 5/8" ID (21")
			1 Coupler Hump 3-1/2" x 3"	1 hose 3/4" ID (28")
			4 M6 Washer Wavy	1 MAF sensor gasket
				1 Grommet Temp. sensor
				1 Plastic plug
				1 Vacuum cap 3/4"
				1 M6x1x12 Screw
				1 M6 Washer
				2 Locknut Nylon
				1 MAF sensor tube
				2 M4x.7x16 screws
				2 Nylon Spacers




Complete kit with parts.




Complete stock intake.




Remove the three 10mm bolts holding the throttle body cover..




Loosen the factory hose clamp on the throttle body, and the 3/4" idle air bypass hose and the 5/8" breather hose. On some 04-05 models the IAB is not present.




Unplug the IAT sensor and remove the intake duct from the engine. On some 04-05 models the IAT sensor is not present.




Lift air filter housing by pulling straight up it is held in place with 2 rubber gromets. On the back side of the canister is the MAF harness. Unplug harness from vehicle and remove.



Separate the filter canister by unfastening the band clamp and removing the air filter. Disconnect the harness from the MAF sensor. Remove the MAF sensor from the factory airbox. Using supplied screws, spacers and gasket to reinstall sensor onto MAF sensor tube.



Mount the MAF sensor tube using the supplied gasket to the outside of the air filter housing, use injection molded adapter on filter side. Use the (4) M6x1x20 screws and tighten down with a 10mm wrench.




Remove the 8mm bolt that secures the cruise control (see arrow). Insert the plastic spacers into the rubber gromets. On the 04-05 models there is no cruise control bracket. A m6 screw and washer is provided.



Insert the air filter housing into the engine bay and bolt down the housing to the bottom bracket with the supplied nuts and bolts. Reinstall the 8mm bolt that secures the cruise control.




Install the hump hose and clamps on the air filter housing and install the 3" straight coupler and clamp on the throttle body



Install the smaller end of the intake tube into the throttle body coupler and insert other end into the hump coupler on the housing. Tighten down clamps on both couplers.



Install the rubber grommet into the IAT sensor location. Reinstall the IAT sensor and reconnect harness. At this time plug the MAF sensor into the harness and secure harness on the side of the housing with the included mounting holes. If you do not have a IAT sensor use the provided grommet and cap to seal the opening.



Install the 3/4" idle air bypass hose and the 5/8" breather hose on the intake tube and tighten down clamps. If you do not have a idle air bypass valve seal with the provided 3/4" vacuum cap. Install air filter and tighten the clamp.



Your installation is now complete. Close hood slowly to verify hood clearance. Check and retighten connections and filter after a few hours of operation.

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" aFe P/N: 90-50001 blue oil aerosol, or aFe P/N: 90-50501 blue squeeze bottle oil on Filter Replacement: PN: 24-90039 (black w/blue media).