INSTALLATION INSTRUCTIONS

▲ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Ford	Taurus
Mercury	Sable

WIRING LOCATION GUIDE


PASSENGER CARS (P)

Representative vehicle shown below

- P3 Behind driver side taillight housing, inside of trunk
- P4 Behind passenger side taillight housing, inside of trunk

CUSTOM WIRING HARNESS





NOTICE 🗇 🕮

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Panel trim removal tool



Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS 🕮

Step 1

Open the vehicle tailgate. Remove the rear scuff panel and partially remove the felt trunk liner behind the taillights by removing the plastic fasteners holding them in place (A,B).

Step 2


Starting on the driver side, behind the felt liner, locate the vehicle taillight wiring harness connectors (C). The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs.

Step 3

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (D).







end with the green wire.

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

Route the custom wiring harness end with the green wire

to the passenger side behind the removed scuff panel. Repeat steps 2-3 on the passenger side using the harness

Step 6

Step 4

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.



