FORM#40027.02-080117 PRINTED IN U.S.A. PAGE 1 OF 6



SUPERLIFT® Level-It 2004-2014 FORD F-150 2WD & 4WD INSTALLATION INSTRUCTIONS

INTRODUCTION

Installation requires a professional mechanic. The overall vehicle must be in excellent working condition; repair or replace all worn parts.

Read instructions several times before starting. Be sure you have all needed parts and know where they install. Read each step completely as you go.

NOTES:

- Prior to beginning the installation, check all parts and hardware in the box with the parts list below. If you find a packaging error, contact Superlift® directly. Do not contact the dealer where the system was originally purchased. You will need the control number from each box when calling; this number is located at the bottom of the part number label and to the right of the bar code.
- Front end alignment is necessary.
- A foot-pound torque reading is given in parenthesis () after each appropriate fastener.
- Prior to attaching components, be sure all mating surfaces are free of grit, grease, excessive undercoating, etc.
- A factory service manual should be on hand for reference.
- Use the check-off box "□" found at each step to help you keep your place. Two "□□" denotes that one check-off box is for the driver side and one is for the passenger side. Unless otherwise noted, always start with the driver side.

FORM#40027.02-080117 PRINTED IN U.S.A. PAGE 2 OF 6

DISASSEMBLY

NOTE: Save all factory components and hardware for reuse, unless noted.

1) PREPARE VEHICLE □ Place vehicle in neutral. Raise front of vehicle with a jack and secure a jack stand beneath each frame rail, behind the lower control arms. Ease the frame down onto the stands, place transmission in low gear or "park", and chock rear tires. Remove front tires.
2) EPAS and BRAKE HOSES On 2011 and up models equipped with electronic power assist steering (EPAS) must have the plugs disconnected before installation begins. They are located on the steering assembly by the front differential.
□□ Remove the bolt securing the rubber brake hose-to-frame.
3) ANTI-SWAY BAR □ The anti-sway bar links connect the bar body to the lower control arms. On each side, disconnect the links from the bar body.
NOTE: Steps 4 through 12 are performed one side at a time.
4) AXLE SHAFTS □□ Remove the bolts securing the axle shaft to the differential flange.
5) TIE-ROD ENDS □ Remove the nut securing the tie rod end to the knuckle. Using the appropriate puller tool, separate the tie rod end from the knuckle.
6) CONTROL ARM BOLTS IMPORTANT: Eccentric cam bolts connect the lower control arm-to-frame, and are also used for front end alignment. In later steps the eccentrics must be restored to their pre-lift position for alignment to be "in the ball park" prior to final alignment. Prior to loosening, scribe a line on each eccentric washer, and the flanges they contact, for later reference.
□□ Loosen, do not remove, all four control arm-to-frame bolts (both upper and lower control arms).
7) COIL STRUT REMOVAL □ Mark the position of the coil struts so that they can be installed on the appropriate side and orientation during reassembly.
□□ Support the lower control arm with a floor jack. Remove the bolt that attaches the strut-to-lower control arm. NOTE: 2014 model vehicles have a bar pin in the lower strut mount with two bolts going through the lower control arm. Remove the two nuts and proceed following the instructions. Remove the three nuts securing the strut assembly-to-frame.
□□ Remove the nut securing the upper ball joint-to-knuckle. Using the appropriate puller tool, separate the ball joint from the knuckle.

FORM#40027.02-080117 PRINTED IN U.S.A. PAGE 3 OF 6


 \Box While holding the top of the knuckle, lower the control arm enough to facilitate removing the strut assembly.

NOTE: When removing the strut, it is helpful to rotate the knuckle to gain clearance between the lower strut mount and axle shaft.

ASSEMBLY

8) STRUT SPACER...

□□ [Illustration 1] Install the 3/8" x 2" bolts into the bottom of the spacer as shown. Make sure the bolts are seated properly within the spacer.



□□ Mate the strut assembly's upper end to its frame mount; align the scribe marks made in step 7. Secure with the supplied 3/8" flange nuts, snug but do not tighten.



□□ Raise the lower control arm, and attach the bottom of the strut assembly-to-lower control arm using the factory hardware. Do not tighten at this time. This may require loosening of the upper strut flange nuts.

9) BALL JOINTS, TIE RODS...

□□ Reattach the upper ball joint-to-knuckle (85). Attach tie rod end-to-knuckle (111).

10) AXLE SHAFTS...

□□ Line the axle shaft up with the differential flange, and secure using the factory hardware (60).



11) ANTI-SWAY BAR...

□□ Connect the sway bar end link to the sway bar body using the factory hardware (98).

12) BRAKE HOSES...

□□ Reattach the rubber brake hose-to-frame and secure using the factory hardware.

Repeat steps 4 through 12 on opposite side.


FORM#40027.02-080117 PRINTED IN U.S.A. PAGE 4 OF 6

13) TIRES / WHEELS...

□□ Tighten the lug nuts (150) in the sequence shown.

WARNING: When the tires / wheels are installed, always check for and remove any corrosion, dirt, or foreign material on the wheel mounting surface, or anything that contacts the wheel mounting surface (hub, rotor, etc.). Installing wheels without the proper metal-to-metal contact at the wheel mounting surfaces can cause the lug nuts to loosen and the wheel to come off while the vehicle is in motion.

WARNING: Retighten lug nuts at 500 miles after any wheel change, or anytime the lug nuts are loosened. Failure to do so could cause wheels to come off while vehicle is in motion.



14) INITIAL CLEARANCE CHECK...

□□ With the vehicle's frame rails still on jack stands, and the suspension "hanging" at full extension travel, cycle steering lock-to-lock and check all components for proper operation and clearances. Pay special attention to the clearance between the tires / wheels and brake hoses, wiring, etc.

15) TIGHTEN REMAINING FASTENERS...

□□ Lower vehicle to the floor.	The suspension	is now supporting	vehicle weight.	On each side,
tighten:				

	2009-2013 St	ut assembly	y-to-lower	control a	arm (351)	
--	--------------	--------------------	------------	-----------	-----------	--

	2014	Strut	assemb	oly-	to-	lower	contro	l arm ((70`).
--	------	-------	--------	------	-----	-------	--------	---------	------	----

□□ Strut assembly-to-upper tower (30).

□ Upper control arm-to-frame (114).

□□ Lower control arm-to-frame (259). Prior to tightening the lower control arm eccentric cam bolts, align the scribe marks made in step 6.

16) FINAL CLEARANCE CHECK...

□□ Cycle steering lock-to-lock and inspect the tires / wheels, and the steering, suspension, and brake systems for proper operation, tightness, and adequate clearance. Pay close attention to knuckle and tire / wheel clearance.

17) HEADLIGHTS...

Readjust headlights to proper setting.

18) ALIGNMENT...

Realign vehicle to factory specifications.

19) SUPERLIFT WARNING DECAL...

☐ Install the "WARNING TO DRIVER" decal on the inside of the windshield, or on the dash, within driver's view.

FORM#40027.02-080117 PRINTED IN U.S.A. PAGE 5 OF 6

20) SUPERLIFT BADGES...

☐ This kit is packaged with a small Superlift badge for a location of your choosing. Prior to installation, use the supplied alcohol pad to eliminate all soap and or other non-adhering residues tha may impair adhesion, thoroughly clean the entire area of placement.
Remove the adhesive back and place in the desired location. The adhesive on our badges is pressure sensitive and must be applied using pressure on all areas of the graphic. Like any PSA (pressure sensitive adhesive), it can take up to 72 hours for the adhesive to fully cure. Once the badge is in place do not peel it up, this will diminish the adhesive properties and could result in damaging the badge itself.
□ To keep your Superlift badge in "like new" appearance keep the badge free/clear of solvents and chemicals that could cause the adhesive to dry or dissolve. This includes gasoline, diesel fuel, paint thinner, and alcohol. Soap and water is all that is needed for cleaning. Degreasers can be used sparingly and hand wiped / applied if needed, although not suggested.

Important Maintenance Information

It is the ultimate buyer's responsibility to have all bolts / nuts checked for tightness after the first 100 miles and then every 1000 miles. The steering, suspension and driveline systems, plus wheel alignment should be inspected by a qualified professional mechanic at least every 3000 miles.

Limited Lifetime Warranty / Warnings

Your SUPERLIFT® product is covered by the Limited Warranty explained below that gives you specific legal rights. This limited warranty is the only warranty SUPERLIFT® makes in connection with your product purchase. SUPERLIFT® neither assumes nor authorizes any retailer or other person or entity to assume for it any other obligation or liability in connection with this product or limited warranty.

Superlift, LLC, Limited Lifetime Warranty

What is covered? Subject to the terms below, SUPERLIFT® will repair or replace its products found defective in materials or workmanship for so long as the original purchaser owns the vehicle on which the product was originally installed. Your warrantor is SUPERLIFT, LLC, doing business as Superlift® Suspension Systems ("SUPERLIFT®").

What is not covered? Your SUPERLIFT® Limited Warranty does not cover products SUPERLIFT® determines to have been damaged by or subjected to:

- Alteration, modification or failure to maintain.
- Normal wear and tear (bushings, rod ends, etc.). Scratches or defects in product finishes (powder coating, plating, etc.).
- Damage to, or resulting from, the vehicle's electronic stability system, related components or other vehicle systems.
- Racing or other vehicle competitions or contests. Accidents, impact by rocks, trees, obstacles or other aspects of the environment.
- Theft, vandalism or other intentional damage.

Remedy Limited to Repair or Replacement. The exclusive remedy provided hereunder shall, upon Superlift's inspection and at Superlift's option, be either repair or replacement of the product covered under this Limited Warranty. Customers requesting warranty consideration should contact SUPERLIFT® by phone (1-800-551-4955) to obtain a Returned Goods Authorization number. All removal, shipping and installation costs are customer's responsibility.

If a replacement part is needed before the SUPERLIFT® part in question can be returned, you must first purchase the replacement part. Then, if the part in question is deemed warrantable, you will be credited / refunded.

FORM#40027.02-080117 PRINTED IN U.S.A. PAGE 6 OF 6

Other Limitations - Exclusion of Damages - Your Rights Under State Law

• Neither SUPERLIFT® nor your independent SUPERLIFT® dealer are responsible for any time loss, rental costs, or for any incidental, consequential or other damages you may have.

• This Limited Warranty gives you specific rights, and this is the only warranty SUPERLIFT® makes in connection with your product purchase. You may also have other rights that vary from state to state. For example, while all implied warranties are disclaimed herein, any implied warranty required by law is limited to the terms of our Limited Lifetime Warranty as described above. Some states do not allow limitations of how long an implied warranty lasts and / or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you. SUPERLIFT® neither assumes nor authorizes any retailer or other person or entity to assume for it any other obligation or liability in connection with this product or Limited Warranty.

Superlift, LLC, Satisfaction Guarantee

We want you to purchase our product with confidence and be 100% satisfied with the end result. If you have any legitimate issue, and SUPERLIFT® cannot rectify it to your satisfaction, SUPERLIFT® will take back the SUPERLIFT® brand product and refund the customer 100% of the product purchase price.

The details:

- Offer valid to the original retail consumer for six months after product purchase.
- May require a SUPERLIFT® dealer's participation in order to assist in "troubleshooting" the issue.
- Any costs related to labor, freight, incidental or consequential are not refunded.
- Refund will not exceed SUPERLIFT'spublished retail price.

Important Product Use and Safety Information / Warnings

As a general rule, the taller a vehicle is, the easier it will roll over. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall"; always use as wide a tire and wheel combination as feasible to enhance vehicle stability. We strongly recommend, because of rollover possibility, that the vehicle be equipped with a functional roll bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capabilities are decreased when significantly larger / heavier tires and wheels are used. Take this into consideration while driving. Also, changing axle gear ratios or using tires that are taller or shorter than factory height will cause an erroneous speedometer reading. On vehicles equipped with an electronic speedometer, the speed signal impacts other important functions as well. Speedometer recalibration for both mechanical and electronic types is highly recommended.

Do not add, alter, or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the SUPERLIFT® product purchased. Mixing component brands is not recommended.

SUPERLIFT SUSPENSION

300 Huey Lenard Loop Rd.
West Monroe, Louisiana 71292
Phone: (318) 397-3000
Sales / Tech: (800) 551-4955
Fax: (318) 397-3040
www.superlift.com