If you have any comments or concerns, please feel free to contact our customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY

fia

FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS FOR TR49-15, TR49-16, TR49-17, TR49-19, TR49-20, TR49-25 OE39-15, OE39-16, OE39-17, OE39-19, OE39-20, OE39-25 SP89-15, SP89-16, SP89-17, SP89-19, SP89-20, SP89-25 SL69-15

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

1) Remove head rest (see note below)
2) Move seat to most forward position
3) Slip cover over backrest and pull down firmly

A) BACKREST COVERS:

4) Tuck flaps through crevice and attach to Velcro at back
5) Replace headrests (see note below)

B) CUSHION COVERS:

1) Center cover on the seat
2) Pass the front strap under seat and buckle to back flap
3) Pass side straps through the opening between the molded plastic and the seat (for TR49-16, TR49-17, TR49-19, Oe39-16, Oe39-17, Oe39-19) **OR** Pass side straps around back of seat (for TR49-15, TR49-20, Oe39-15, Oe39-20)
4) Buckle straps to back flap
5) Adjust straps and buckles to equalize tension

C) BACKREST COVER:

1) Open armrest / storage compartment
2) Center cover under armrest
3) Snug cover at back of armrest so the velcro on the cover is positioned through the crevice where lid and armrest are hinged
4) Position adhesive back Velcro, supplied, to align with the velcro on cover

D) CUSHION COVER – CENTER "20" PORTION (TR49-16, Oe39-16, SP89-16)

1) Center cover on the seat
2) Pass front straps under seat and buckle to back flap
3) Pass side strap around back of seat and buckle
4) Adjust straps and buckles to equalize tension

E) CUSHION COVER – CENTER "20" PORTION (TR49-15, Oe39-15, SP89-15, TR49-17, Oe39-17, SP89-17)

1) Open cushion lid to up position
2) Center the cover on the seat
3) Tuck the back part of cushion cover through seat crevice
4) Pass the side straps under back corners of seat and secure to the end buckles
5) Adjust straps/buckles to equalize tension

NOTES:

1) **SELF-LOCKING SUPER-GRIP® BUCKLE**:

2) HEAD REST REMOVAL:

A) - Insert paper clip into holes at base to release
- Lift off

OR

B) - Push in side release buttons
- Lift off

(If unable to remove consult dealership)

3) RE-INSTALLATION OF HEADRESTS

- Ensure pre-cut holes in seat cover align with holes in base
- Replace headrest

WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.

fia **Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438**
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

5-12-10