



1. Using caution, remove trim plate across bottom of rear cargo door opening (A).
2. Pull driver's side panel out slightly (approximately 4"). The trailer harness mating connector will be visible near the base of the cargo floor (B).
3. Under vehicle, locate and cut a small "X" in the grommet leading to the spare tire compartment. Route white trailer harness connector up through this grommet. Plug into vehicle connector. (TIP: Silicone sealant should be applied around "X" in grommet for waterproofing.)
4. Apply a small amount of grease to all electrical connections to help prevent corrosion.
5. Plug completed wire harness into the trailer connector.
6. Test all functions with engine running to ensure proper operation.

#### TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

- 
1. Con cuidado, remueva la moldura trasera del piso de lado a lado de la abertura de la puerta de carga (A).
  2. Jale la cubierta lateral del lado del conductor ligeramente (aproximadamente 4"). El conector de acoplamiento del arnés del remolque estará visible cerca de la base del piso de carga (B).
  3. Debajo del vehículo, localice la arandela aislante de goma dirigida al compartimiento de la llanta de refacción, corte una pequeña "X" en ella. Dirija el conector blanco del arnés del remolque a través de esta arandela aislante de goma. Enchufe en el conector del vehículo. (Recomendación: debe aplicar sellador de silicón alrededor de la "X" en la arandela de goma para que quede a prueba de agua.)
  4. Aplique una pequeña cantidad de grasa a todas las conexiones eléctricas para prevenir la corrosión.
  5. Enchufe el arnés de cableado completo al conector del remolque.
  6. Para asegurar la operación apropiada, compruebe todas las funciones con el motor funcionando.

#### CONSEJOS:

- La aplicación regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
- Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
- Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.