



1. Locate vehicle taillight wiring harnesses (A). These harnesses will have the same connector ends as the Wiring Kits. Locate connectors under tail lamp assemblies behind bumper on the extreme outside edges of the vehicle.
2. Disconnect vehicle taillight wiring harness. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Apply a small amount of grease to all electrical connections to help prevent corrosion.
4. Plug Wiring Kit (B and C) into the male and female harness plugs. Be sure the connectors are fully inserted with locking tabs in place.
5. Plug completed wire harness (E) into the trailer connector.
6. Test all functions with engine running to ensure proper operation.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.
- Converter maximum load – 2.1 amps. on left and right turn (one bulb on each side).

1. Localice el arnés de cableado de las luces traseras (A). Este arnés tendrá los mismos extremos de conectores que el kit del cableado. Localice los conectores debajo de los ensamblajes de las luces traseras detrás del parachoques en las orillas exteriores extremas del vehículo.
2. Desconecte el arnés de cableado de las luces traseras. Los conectores se desconectarán al oprimir o levantar la lengüeta de cierre y separarlas.
3. Aplique grasa al arnés de cables al extremo del remolque para prevenir la corrosión.
4. Enchufe el kit del cableado (B y C) en los enchufes macho y hembra del arnés. Asegúrese que los conectores estén completamente insertados con las lengüetas de cierre en su sitio.
5. Enchufe el arnés de cableado completado (E) al conector del remolque.
6. Compruebe todas las funciones con el motor corriendo para asegurar la instalación apropiada.

CONSEJOS:

- La aplicación regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
- Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
- Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.
- Carga máxima del convertidor – 2.1 amperios en la direccional izquierda y derecha (una bombilla en cada lado).