

1. Locate vehicle taillight wiring harness by removing the two right hand screws from the driver's side taillight and pulling taillight away from the body.
2. Disconnect vehicle wiring harness behind the left taillight, apply a small amount of grease to all connections, and plug the Wiring Kit into the vehicle wiring harness and into the left taillight.
3. Route the 4-wire flat over or under the frame to the center of the bumper and secure with wire ties.
4. Replace the taillight by installing the two screws removed in step 1.
5. Apply a small amount of grease to the 4-wire flat to prevent corrosion and plug into matching 4-wire flat on trailer.
6. Check all functions with engine running to ensure proper operation.

TIPS:

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

1. Localice el arnes del vehiculo de las luces traseras quitando los dos tornillos al lado derecho de la luz trasera izquierda y retirando las lamparas del ensamble.
2. Desconecte el arnes del vehiculo detras de la luz trasera izquierda, aplique una pequena cantidad de grasa a todas las conexiones, y enchufe el kit del cableado en el arnes del vehiculo y en la luz trasera izquierda.
3. Dirija el conector plano 4 vias por arriba o por abajo del marco al centro de la defensa y asegurelo con corbatas para cables.
4. Reponga la luz trasera instalando los dos tornillos que se quitaron en el paso 1.
5. Aplique una pequena cantidad de grasa al conector plano de 4 vias para prevenir corrosión y enchufelo en el correspondiente conector plano de 4 vias en el remolque.
6. Revise todas las funciones con el motor encendido para asegurar operacion correcta.

CONSEJOS:

- La aplicació n regular de grasa a las terminales de los cables del remolque ayudará a prevenir la corrosión.
- Se puede requerir una señal de destello de alta potencia para eliminar que las luces destellen rápidamente.
- Siempre desconecte el conector del remolque de botes antes de retroceder el remolque dentro del agua.