Kit Part # Make: <u>Model</u>	5/1 Mini 100 Ra Year Engine	bols Required: 16" nut driver or slotted screwdriver mm socket or wrench ttchet and extension	Part List:1Air filter (replacement # 24-90031)1Intake Housing1Mini Clamp #401Trim seal (24")	
Cooper 0. Box 1719 ma, CA 92878 tt: 951-493-7100 .aFefilters.com	'02-'04 L4-1.6L			
1 Contract of the system.	Step 2 Step 2 Step 2 Stock intake system.	Step 3 Step 3 St		Step 5 Step 5 St
	e Step 7	Step 8 Image:	Step 9	Step 10



Install the new air filter into the hosing secure the filter with the provided clamp. The air filter is pre oiled from the factory **Do not use any grease or oil.**



Place enclosed CARB EO sticker on a clean/smooth surface on or near the intake system. EO identification label is required in passing the Smog Check inspection. Your installation is now complete .Make sure you tighten all clamps and check all electrical connections.Re check periodically.