


Intake Kit Installation Instructions: 2003-2007 Ford Super Duty/ Excursion 6.0L V8 Power Stroke (td)



P.O. Box 1719
Corona, CA 92878
Support: 951-493-7100
www.aFepower.com


Kit Part #	54-30392/ 51-30392 75-30392/75-30392-0V	Tools Required	Part List:	2 Spacers, Nylon	Included in Value Pack P/N 75-30392-0V
Make:	Ford	5/16" nut driver or slotted screwdriver	1 Air filter Replacement (24-90037, Pro Dry S 21-90037, Pro GUARD 7 72-90037)	1 3/4 Bulb Trim Seal	
Model:	Super Duty/ Excursion	11mm socket or wrench	1 Filter Housing	1 Gasket	
Engine:	6.0L-V8 TD	Ratchet and extension	1 Intake Tube	1 Torx bit: T20	
Year:	2003-2007	10mm socket or wrench	2 M6 Screw	1 Grommet, Temp Sensor	
			2 M6 Flat Washers	Included in 75-30392-0V only:	
			2 M6 Wavy Washers	1 Spare Filter (21-90037)	
			3 M6 Nut	1 Pre-filter (28-10201)	
			2 8-32 Screws	1 Cleaning kit (90-50500)	




Step 1
Complete kit. Make sure you have all the components before you begin your installation.



Step 2
Complete stock intake.



Step 3
Loosen the hose clamp on the turbo inlet. Carefully disconnect the MAF sensor wiring harness.



Step 4
Disconnect the Filter Minder located on the back of the air filter box.



Step 5
Undo the two retaining clips securing the air box outlet. Lift up and remove the turbo inlet tube and filter lid as one piece.



Step 6
Remove the inlet portion of the air box out of the engine bay.




Step 7
Install supplied 3/4" bulb trim seal. Start at one end of housing and work towards other end.



Step 8
Install Factory filter minder grommet into tube.



Step 9
Reinstall factory accordion coupler onto tube and install tube into vehicle. Do not tighten clamp until final assembly.



Step 10
Install housing into vehicle. (1)Align the housing tab with slot, onto the radiator support stud on the core support. (2)Slide the tube through the housing and align the holes on the housing. (3)Align the tab into the slot on the battery tray.



Step 11
Use supplied M6 hardware (2 Screws, 2 Nuts, 2 Wavy Washers) to mount the tube to the housing.



Step 12
Use supplied (M6 nut, two washers) and tighten housing. Two washers are supplied to allow for a washer on both ends of tab if needed



Step 13
Install Factory MAS onto tube using supplied hardware (2 8-32 Screws, 2 nylon spacers, gasket)



Step 14
Tighten both ends of the factory accordion coupler.



Step 15
Reinstall factory filter minder and connect plug. Install filter and tighten clamp. Your installation is now complete. Make sure you tighten all clamps and check all electrical connections. Re check periodically

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, or aFe P/N: 90-50501 blue squeeze bottle oil or aFe P/N: 90-50000 gold oil aerosol, or aFe P/N: 90-50500 gold squeeze oil). Filter Replacement: Magnum FLOW PN: 14-10093 (black w/blue media), or Pro-GUARD 7™ PN: 71-10093 (black w/gold media). Pro Dry S P/N 21-90037 (black w/ white media) Pro Dry S cleaning: See cleaning instruction sheet 06-00074