



Kit P/N: 54-11648 55-11640 55-11641 Make: BMW Model: Year: Engine: E82(1-Series) 08-09 ALL E88(1-Series) 08-09 ALL <i>Note: Installation is for D.A.S. Only!</i>	Tools Required: Driver w/T25 torx bit	Parts List: 1 05-01033 Driver side <i>D.A.S.</i> 1 05-01032 Passenger side <i>D.A.S.</i> 1 T25 Torx Bit
--	---	---

