



MAF Adaptor Installation Instructions: 2008-2010 Ford Power Stroke V8-6.4L (td)

Kit P/N: 59-90001
 Make: Ford
 Model: Super Duty Year: 2008-2010 Engine: V8-6.4L (td)

Tools Required:
 Flat head screw driver
 Phillips head screw driver

Parts list
 1 - Adaptor, MAF
 2 - Gaskets, MAS
 2 - Screws, Phillips
 2 - Screws, Slotted
 1 - Air Filter, 72-90049
 1 - Pre-Filter, 24-91039



Place single gasket on MAF pad



Install bracket using 2 Phillips head screws, make sure that it is on correctly. Please use FIG. A and B as reference to a proper install.



Place gasket over MAF sensor.



install MAF sensor using Flat head screws. Your installation is now complete.



INCORRECT: If there is an overlay it will not allow the MAF sensor to be installed correctly. Turn 180° and it will correct this issue.



CORRECT