



Figure G

Refer to Figure G for step 8

Step 8: Connect the air filter adaptor to the aFe air intake tube using the supplied elbow coupler. Align the air intake tube prior to tightening the clamps and mounting bolt. Install the MAF sensor in the aFe air intake tube using the supplied screws.



Figure H

Refer to Figure H for step 9

Step 9: Check that all components are tight and secure. Your installation is now complete.

NOTE: Retighten all connections after approximately 100-200 miles.