



P.O. Box 1719
 Corona, CA 92878
 Support: 877-512-8111
 www.aFeFilters.com

Air Filter Installation Instructions - Ford Power Stroke V8-6.0L (TD)

Part #	10-10100 / 71-10100	Tools Required:	Parts List:
Year	2003-2006	Knife	1 Air Filter
Make	Ford		
Model	F250/F350/F450/F550		
	Excursion		
Engine	V8-6.0L (TD) Power Stroke		



Step 1
 Remove the intake system which includes the air filter. Separate the air filter from the intake system.



Step 2
 With a knife or sharp blade carefully cut along the edge of the OE air filter from the side opposite seal. Discard the air filter internals.



Step 3
 Carefully slide the air filter into the canister as shown above. Pay close attention to the alignment of the mounting slots relative to the filter housing.



Step 4
 Re-assemble the air filter assembly. Verify engagement grooves are positioned as shown to ensure correct installation. Reinstall assembly back into engine.

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" aFe P/N: 90-50000 gold oil aerosol, or aFe P/N: 90-50500 gold squeeze bottle oil