



advanced FLOW engineering
P.O. Box 1719
Corona, CA 92878
Support: 951-493-7100
www.aFeFilters.com

aFe Silver Bullet

Throttle Body Spacer
Part Number
46-36002

Important!

This kit includes the parts for several different installations; please verify the parts list and read all instruction steps before you begin installation.

Make: NISSAN TRUCK/SUV

| Model | Year | Engine | Model | Year | Engine |
|------------|-----------|--------|--------|-----------|--------|
| Frontier | 2005-2008 | 4.0L | XTerra | 2005-2008 | 4.0L |
| Pathfinder | 2005-2008 | 4.0L | | | |

1. Loosen and remove engine cover. Loosen and remove PCV vent hoses from air inlet tube. Loosen and remove air inlet tube from throttle body and air filter assembly.
2. Loosen and remove the four socket cap bolts from the throttle body with a 5mm hex. Remove throttle body away from intake manifold.
3. Install the aFe Silver Bullet Spacer (engraved side towards throttle body) and a gasket onto the manifold with the longer bolts and washers (supplied in kit). Tighten the bolts to 10 Nm (89 lb/in).
4. Install air inlet tube onto the throttle body and air filter assembly. Reconnect the PCV vent hose to air inlet tube. Reinstall the engine cover.

Parts List

- 1 aFe Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 80mm bolts
- 4 6mm flat washers
- 4 6mm lock washers