



Description: Tail light
Part Number: 311048-311092
Application: 2007-2008 Toyota Tundra



Tools needed: T27 Torque bit
socket.

Step 1: Use the t27 torque bit
socket to remove the two
screws holding in the tail light.



Step 2: Under the vehicle bed
unplug the wire harness.

Step 3: Unclip the wire
harness from the frame.

Step 4: Take the tail light off
from the vehicle.



Step 5: Put in the new Anzo
led tail light into the vehicle.

Step 6: Plug in the new Anzo
wire harness into the original
socket of the vehicle.

Step 7: Test all functions
making sure they work
properly before driving.



AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

