ANZO USA

www.anzousa.com

STOP

Read complete instructions before installation! Improper installation may void warranty

Description: Corner Step Lights
Part Number: 861145
Application: 2014 Chevy Silverado/ 2014 Gmc Sierra

Tools needed:
T15 torx bit
9/32 socket
1/4 ratchet
1/4 inch extension
1/4 inch swivel adapter
Wire crimpers
Wire splicers

Remove the 2 torx screws located at the top of your step pocket.

Remove the 2 screws at the bottom of the step pocket under the bumper.

Gently pull back the top of the step pocket and the is a screw on either side that needs to be removed.

Once the 6 screws holding the pocket to vehicle are removed the pocket will come out.

Slide the stock step out of the pocket and feel the wires and new step in place of the old one.

The wires will be coming out of the back of the pocket like this.

Replace the pocket back on the vehicle by reversing the removal procedure.

There are 4 wires that need to be connected. Black is ground, green is turn signal positive, blue is running light positive and white is reverse positive. These can be connected to the taillight wiring or the trailer wiring.

Splice the wires as followed
Black to Black
Green to Green
Blue to Brown
White to Green on reverse light
Repeat this process for the other side.

Check all functions of the light once it is connected.