



## INSTALLATION INSTRUCTIONS

### #201-712 AIRAID JR. KIT

### 99-06/2007 "CLASSIC" CHEVY/GMC PU/SUV 4.8, 5.3, 6.0L WITH MECHANICAL COOLING FAN

Thank you for purchasing the Airaid Modular Intake Tube. Please read this instruction manual carefully before proceeding with the installation. Contact Airaid @ 800-498-6951 8:00 AM – 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Modular Intake Tube was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact Airaid.

***THANK YOU FOR SELECTING AIRAID.***



#### **Packing List:**

851-135	Airaid Premium Filter	1
KIT912T	Modular Intake Tube	1
KITHUMPHS02	Urethane Hump Hose	1
KITCOUPLER02	Coupler W/ #68 Clamp	1
KITHS60	#60 Hose Clamp	2

#### **Tools Required for this Installation:**

Flat Head Screwdriver



# Installation Instructions. Read Me!

## I DISCONNECT NEGATIVE (-) BATTERY CABLE

## II Remove Factory Intake Assembly

- Loosen the factory hose clamps on each end of the factory intake tube assembly.
- Using a flat head screwdriver, gently pry the radiator hose bracket from the factory intake tube assembly and remove from vehicle. See Fig #1 & Fig #2

## III Airaid Modular Intake Tube Installation

- Install the provided coupler with clamp, onto the Airaid Modular Intake Tube (MIT). See Fig # 3
- Install the urethane hump hose provided onto the Airaid Modular Intake Tube (MIT) with the supplied hose clamps. (Hint: slide the hump hose all the way onto the end of the MIT. See Fig #4
- Install the Airaid MIT in place of the factory intake tube assembly. See Fig #5
- Check for interference and adjust the MIT accordingly, then tighten the hose clamps.

## IV Airaid Jr. P/N 201-712 Replacement Filter

- If you purchased the Airaid Jr. kit P/N 201-712, replace the factory air filter with the Airaid Premium Filter included in the Airaid Jr. kit.

## V Finishing Up

- Make sure that the intake path is clear of debris.
- Double check work to ensure proper fit and that all clamps are securely fastened.
- Re-connect negative battery cable.

**Note:** A Provision has been made to mount the factory filter minder onto the MIT Intake Tube . A 17mm hole must be drilled on the back side of the tube. A circular impression on the rear of the tube indicates the correct hole location. Use the factory grommet to mount the filter minder. See Fig #6

Figure #1



Figure #2



Figure #3



Figure #4



Figure #5



Figure #5



Synthamax Air Filters do not require oil. Service air filter as needed by cleaning with common non-petroleum all-purpose household cleaner and water. Simple Green®, Formula 409® or equivalent works great. Apply cleaner to outside of air filter and allow to soak. Then flush filter clean from the inside out with a garden hose and repeat steps if necessary. Do not apply high pressure water or air to clean filter. Allow filter to air dry and reinstall.

Optional:  
Installation of Factory Filter Minder in MIT Tube

**SynthaMax**

**Do Not Oil**

Rev. 10/26/10