



300-561 INSTALLATION INSTRUCTIONS 87-00 Dodge Caravan/Plymouth Voyager 3.0, 3.8L

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Contact AIRAID @ (800) 498-6951 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact AIRAID.

Thank you for selecting AIRAID.



Parts List

- (1) Power Plate
- (2) Gaskets
- (2) 8mm x 3 1/4 Bolts
- (2) 8mm Washers

Tools List

- 13mm Socket
- Standard Screwdriver

Installation Instructions. Read Me!

1. **DISCONNECT NEGATIVE (-) BATTERY CABLE.**
2. Remove throttle body air intake assembly.
3. Remove (2) nuts from the throttle body and (2) studs from manifold. (**Ref. "C"**)
4. Remove gasket and clean surfaces.
5. Install power plate with (2) gaskets.
 - A. Locate one gasket between the throttle body and power plate.
 - B. Locate second gasket between power plate and manifold.
6. Install (2) bolts and washers using **Step 3** as an example.
7. Inspect & Test the throttle linkage for full Open & Closed travel before driving. Some cruise or kickdown cables may require adjustment. Please refer to your vehicles service manual for proper adjusting.
8. Reinstall the throttle body air intake assembly using **Step 2** as an example.
9. Reconnect battery cable. Enjoy!

The sound of power...The "whistle" means its working!

Ref. "A"- (1) Power Plate
(2) Gaskets



Ref. "B"- Throttle Body

Ref. "C"- (2) 8mm x 3 1/4 Bolts
(2) Gaskets