



## # 300-569 INSTALLATION INSTRUCTIONS 1992-2001 Dodge Dakota/Durango 2.5L

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Contact AirAid @ (800) 498-6951 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact AirAid.

*Thank you for selecting AirAid.*



### **Parts List**

- (1) Power Plate
- (2) Gaskets
- (4) Bolts 6mm x 50mm
- (4) Washers 6mm
- (2) Spacers 1" long
- (2) Bolts 6mm x 40mm

### **Tools List**

- 10mm Socket
- Flat Head Screwdriver

## ***Installation Instructions. Read Me!***

1. **DISCONNECT NEGATIVE (-) BATTERY CABLE.**
2. Remove throttle body air intake assembly.
3. Remove (4) bolts from throttle body (**Ref. "B"**).
4. Remove gasket and clean surfaces.
5. Install power plate (**Ref. "A"**) with (2) gaskets.
  - A. One gasket located between throttle body and power plate.
  - B. One gasket located between power plate and manifold.
6. Replace (4) bolts and washers (**Ref. "B"**) using (**Step 3**) as an example.
7. Inspect & Test throttle linkage for full open & closed travel before driving. Some cruise or kick-down cables may require adjustment. Refer to service manual for proper adjustment.
8. Install (2) spacers and (2) 6mm x 40mm bolts (**Ref. "C"**) on models requiring air intake to throttle body support.
9. Reinstall throttle body air intake assembly using (**Step 2**) as an example.
10. Reconnect battery cable. Enjoy!

***The sound of power...The "whistle" means its working!***

**Ref. C-** (2) Spacers  
(2) Bolts 6mm x 40mm



**Ref. B-** (4) Bolts 6mm x 50mm  
(4) Washers 6mm

**Ref. A-** Power Plate  
(2) Gaskets