

# INSTALLATION INSTRUCTIONS

## 2011 JEEP GRAND CHEROKEE

### PART # 1052 / 1052-2

#### PARTS LIST:

Qty	Description	Qty	Description
1	Grill Guard	12	12mm Flat Washers
1	Driver/Left Frame Mounting Bracket	6	12mm Hex Nuts
1	Passenger/Right Frame Mounting	2	8mm x 25mm Hex Head Bolts
1	Driver/Left Upper Brace Bracket	8	8mm Flat Washers
1	Passenger/Right Upper Brace Bracket	2	8mm Lock Washers
6	12mm x 35mm Hex Bolts	2	8mm nuts
6	12mm Lock Washers		

**Passenger/Right  
Side Frame  
Mounting Bracket**



**Driver/Left  
Side Frame  
Mounting Bracket**



**Passenger/Right  
Side Upper Brace  
Bracket**



**Driver/Left  
Side Upper Brace  
Bracket**



## PROCEDURE:

1. **REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**
2. Start by removing front plastic skid shield from under the vehicle, using a flat tip screwdriver pry the tabs out from the valance and remove the plastic push pins, the 3 bolts in front & the 1 bolt per side of vehicle holding the side of the plastic skid shield in the wheel wells followed by the bolts securing the metal skid shield to vehicle towards the back of vehicle. As seen in **(Fig 1 & 1A)** there is also a plastic insert to be removed; this plastic insert is tucked in and above the bottom lip of the bumper this is to be removed to expose front bolts holding front of tow hook **(Fig 2)** shows insert install **(Fig 2A)** shows plastic insert removed.
3. Once skid shield is removed, starting with the Passenger/right side you will need to remove the tow & the tow hook housing as it is a two piece per side assembly, first locate and remove the large nut on the back side of tow hook **(Fig 3)** shows nut, with the nut removed begin to remove the two factory front bolts holding the front of the tow hook in place as seen in **(Fig 4)**, tow hooks will slide forward out from bumper **NOTE:** (tow hooks will not be reattached after Grill Guard mount brackets are installed) with the tow hooks removed, remove the 2 bolts securing the tow hook housings to the bottom of the frame. **(Fig 5)** shows tow hook housing bolts to be removed.
4. Select the Passenger/right side mounting bracket from the list of parts above, with the bolts that held the tow hook housing to the frame attach the Grill Guard mounting bracket to the bottom of the frame rail as the tow hook housing was attached **(Fig 6)** shows start of brackets attached to frame rail bottom. Snug but do not tighten hardware.
5. Repeat steps 3-4 for Driver/left mounting bracket. Snug but do not tighten hardware.
6. With help, position the grill guard to the Mounting Brackets **NOTE:** brackets go to the inside of grill guard, secure using the included (6) 12mm x 35mm Hex Head Bolts, (6) 12mm Lock Washers, (12) 12mm Flat Washers & (6) 12mm Nuts. **(as seen in Fig 7)** Snug but do not tighten hardware at this time.
7. Open the Hood of the vehicle and locate the (2) fasteners on the radiator support holding the plastic cover **(Fig 8)** shows driver side left with these bolts removed place (2) per side 8mm flat washer into the holes **(these are used as shims to avoid flattening the plastic)** **(Fig 9)** shows washer in place. With the washers in place locate the driver/left side upper brace bracket and attach with the factory bolt throw the 8mm flat washers you just placed into the holes, **(Fig 10)** shows driver side installed. Repeat this step for passenger/right side brace bracket installation Snug but do not tighten.
8. Align hole in the driver/left side brace bracket with hole in the Grille Guard plate. Attach the Top bracket to the Grille Guard with the included (1) 8mm x 25mm hex bolt, (2) 8mm Flat Washers, (1) 8mm lock washer and (1) 8mm Nut, **(Fig 11)**. Repeat this step for passenger/right side brace bracket installation. Do not tighten hardware at this time.
9. Level and adjust the Grill guard and tighten all hardware, With the Grill guard secured begin to re-install the plastic insert behind bumper & secure skid shield with the factory fasteners.
10. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For stainless steel:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Product.

**For gloss black finishes:** Mild soap may be used to clean the Product.





