

# INSTALLATION INSTRUCTIONS

2010-11 TRANSIT PYLON HOLDER

PART # 11130CN

## PARTS LIST:

Qty	Description	Qty	Description
1	Pylon Bracket	2	10mm x 25mm Hex bolts
4	10mm Flat washers	2	10mm Nuts
2	10mm Lock Washers		

## PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.
2. Place the Pylon holder up to the Aries bumper previously installed & attach the Pylon holder to bracket with the (2) 10mm Hex Bolts, (4) 10mm Flat Washer, (2) 10mm Lock Washers & (2) 10mm Nuts (**Fig 1**). Snug but do not tighten hardware level and align Pylon holder properly; then tighten all hardware at this time.
3. Do periodic inspections to the installation to make sure all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For stainless steel:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

**For gloss black finishes:** Mild soap may be used to clean the product.

