

INSTALLATION INSTRUCTIONS OVAL TUBE

229006 / 229006-2 NISSAN TITAN CREW CAB 229007,229007-2 NISSAN TITAN EXT. CAB

PARTS LIST

- (1) Aries Side bar passenger side
- (1) Aries Side Bar Driver side
- (2) Front mount brackets
- (2) Middle mount brackets
- (2) Rear mount brackets

- (12) 3/8"x1" button head bolts
- (12) 3/8"sae black flat washers
- (12) 5/16" USS zinc flat washer
- (6) 8mm 1.25 x 25mm zinc hex bolt
- (6) 8mm 1.25 zinc nut

PROCEDURE

- 1. Begin installation by working on driver side of the vehicle starting at the front of the <u>inner</u> rocker panel.
- 2. Located on the inside as well as the bottom inner of the rocker panel you will see one thread hole and one thread stud for each mounting bracket refer to diagram 1.(Note all brackets are labeled)
- 3. Install mounting brackets to inner rocker panel using 8mm 1.25 x 25 mm bolts plus 8mm nuts and washers as shown in diagram 2.Hand tighten only.
- 4. Attach side bar to brackets using the 3/8" button head bolts and washers. Align the side bar with the vehicle body, then tighten & torque all fasteners to: (30ft/lbs). Repeat steps for passenger side to complete installation.

DIAGRAM 1.

DIAGRAM 2.



FINISH PROTECTION- ARIES PRODUCTS HAVE A HIGH FINISH THAT MUST BE MAINTAINED SUCH AS ANY OTHER HIGH FINISH PRODUCT ON THE VEHICLE. PROTECT THE FINISH WITH A NON-ABRASIVE AUTOMOTIVE WAX. THE USE OF SOAP, POLISH, OR WAX THAT CONTAINS ABRASIVES IS DETRIMENTAL, AS THE COMPOUNDS SCRATCH THE FINISH AND OPEN IT TO CORROSION.

DISCLAIMER- BUYER ASSUMES ALL RISK AND LIABILITY WHATSOEVER FROM THE INSTALLATION AND USE OF ARIES PRODUCTS. ARIES PRODUCTS ARE SOLD AS DECORATIVE ACCESSORIES AND SHOULD NOT BE RELIED UPON AS PROTECTION FOR THE VEHICLE OR OCCUPANTS IN THE EVENT OF A COLLISION OR ROLL OVER. ARIES AUTOMOTIVE ASSUMES NO LIABILITY FOR INJURY, LOSS, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN THE EVENT OF A COLLISION OR ROLLOVER.