



INSTALLATION INSTRUCTIONS
Back Bumper PART #302504
2008-09 SMART CAR

PARTS LIST

- 1- ARIES REAR BUMPER
- 2- SPACERS
- 2- FACTORY SIZE BOLTS
- 2- ½" FLAT WASHER

INSTALLING THE MOUNTING BACK BUMPER

1. Remove the factory hole plugs for the tow hook (located in the back bumper 1 per side (diagram 1)).
2. Attach the washers and bolts through the back bumper guard followed by the spacer.
3. With assistance fasten the back bumper bolts into the factory tow hook holes.
4. Fasten, align the back bumper, and then tighten

Diagram 1

