


# INSTALLATION INSTRUCTIONS

2012-13 FIAT LOUNGE / POP SIDERAIL



PART# 505556 / 505556-2

## PARTS LIST:

Qty	Description	Qty	Description
1	Driver/Left Side Rail	4	10mm Flat Washer
1	Passenger/Right Side Rail	4	10mm Lock Washer
4	10mm x 38mm Bolt Plate	4	10mm Hex Nuts
4	Plastic retainers		



Front of Vehicle →



10mm x 38mm Bolt Plate  
(pictured with Plastic  
Retainer installed for  
example)

## PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

2. Starting by partially threading a Plastic Retainer onto the threaded end of (2) Bolt Plates, **(Fig 1A) above shows one example.**
3. With the bolt plates ready, Starting on the Passenger/right side front Insert the Bolt Plate into the factory floorboard hole, located just under vehicles floor board behind front tire, Once the Bolt Plate is inserted, hold the Bolt end with one hand and tighten the Plastic Retainer with your other hand, **NOTE:** Tighten the Plastic Retainer until it reaches the floor panel. **(Fig 2)** Shows Bolt Plate installed with out plastic retainer for view.
4. Next proceed with the passengers/right side rear you will need to remove the black plastic panel, covering the mounting hole, there are (3) Philips screws along the edge of the rocker panel remove these first followed by the (2) plastic push pins at the rear of this plastic panel, next (1) Philips head screw towards the front of the panel and 1 plastic nut towards the front middle **(Fig 3)** shows location of screws, push pins & Nut to be removed.
5. With the plastic panel removed locate the rubber plug as seen in **(Fig 4)**, remove this plug and place the Bolt plate threw the hole Once the Bolt Plate is inserted, hold the Bolt end with one hand and tighten the Plastic Retainer with your other hand, **NOTE:** Tighten the Plastic Retainer until it reaches the floor panel. **(Fig 5)** Shows Bolt Plate installed with out plastic retainer for view.
6. Next with the bolt plate in place hold the plastic panel up to where it comes in contact with the bolt plate and trim a section of it off so the bolt plate will slide through the plastic panel **(only trim what is needed)** re install the plastic panel with the factory screws, plastic nut and push pins.
7. Select the Passengers/right side rail and begin to install it to the bolt plates by attaching it to front bolt plate, with (1) 10mm Flat Washer (1) 10mm Lock Washer and (1) 10mm Nut, as shown in **(Fig 6)** next install the rear mounting bracket to the rear bolt plate, with (1) 10mm Flat Washer (1) 10mm Lock Washer and (1) 10mm Nut, Snug but do not tighten hardware at this time. **(Fig 7)** shows installation without the plastic panel for view.
8. Align Side rail to the desired location; then tighten all hardware.
9. Repeat steps 2-8 for Driver/left Side rail.
10. Do periodic inspections to the installation to make sure all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For stainless steel:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

**For gloss black finishes:** Mild soap may be used to clean the Sidebar.

Passenger/right side shown

