



INSTALLATION INSTRUCTIONS
BACK BASKET PART #BK2504-2
451 SMART CAR

PARTS LIST

- 1- ARIES REAR BASKET
- 2- SPACERS
- 2- BOLTS
- 2- 1/2 FLAT WASHERS

INSTALLING THE BACK BASKET

1. Remove the factory plastic hole plugs for the tow hook (located in the back bumper 1 per side -diagram 1).
2. Using the bolts and washer, supplied in the kit, place the washers through the bolts and the rear basket mounting points followed by the spacer.
3. With someone helping you fasten rear basket to the factory tow hooks area, align the basket and tighten Diagram 2 finished product

Diagram 1 back bumper mounting point (factory tow hook area)



Diagram 2

