

INSTALLATION INSTRUCTIONS

PART #SMBOLT HK

02-2010 MINI COOPER / 97-2010 SMART CAR / BMW

PARTS LIST:

Qty	Description	Qty	Description
1	21mm x Tow Thread Bolt	2	8mm Flat Washers
1	8mm x 30mm Bolt (Mate)	1	8mm Lock Washers

PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.
2. Carefully remove plastic cap located on front (or back) bumper of vehicle (**Fig 1**).
3. Insert 21mm hex head x thread bolt into exposed hole. Tighten with 21mm socket (**Fig 2**).
4. Attach bracket, or plate using the 8MM mating bolt, lock washer and washer. Add 8MM Washers if needing to extend the 21mm hex head out from bumper (**Fig 3**).

