



BBK Phenolic Spacer Kits

Part # 1506,1508,1520,1530,1549



Special Tools

Required:

- No special tools required

Install Time:

Approximately
1 Hour

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Disconnect the throttle duct hose from the throttle body.

STEP 2

- Disconnect the throttle linkage from the throttle body and also the kick-down linkage if applicable.

STEP 3

- Disconnect the wire connectors from the upper manifold and also the vacuum lines on the underside of the upper intake.

STEP 4

- Remove the cover plate from the upper intake if equipped. Next remove the six bolts from the upper intake manifold.

STEP 5

- Lift off the upper intake and discard the gasket, also making sure both surfaces are free from dirt and grease.

STEP 6

- Next install the phenolic spacer by placing a new gasket on both sides of the spacer.

STEP 7

- Use the new bolts provided and tighten in a criss-cross pattern beginning with the center bolts.

STEP 8

- Next simply reverse the previous steps.



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube
www.youtube.com/bbkperformance

GO TO NEXT PAGE

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-003



BBK Phenolic Spacer Kits

Part # 1506,1508,1520,1530,1549

Hardware Included

1506- Phenolic Spacer (1pc)
 HDW009- Bolt, 5/16-18x2" (4pcs)
 HDW010- Bolt, 5/16-18x6.5" (2pcs)
 HDW090- Flat Washer 5/16x9/16 (6pcs)
 GSK004- Gasket (2pcs)

1508- Phenolic Spacer (1pc)
 HDW009- Bolt, 5/16-18x2" (4pcs)
 HDW010- Bolt, 5/16-18x6.5" (2pcs)
 HDW090- Flat Washer 5/16x9/16 (6pcs)
 GSK005- Gasket (2pcs)

1520- Phenolic Spacer (1pc)
 HDW017- Bolt, 5/16-18x1.75" (1pc)
 HDW018- Hex Nut, 5/16-24 (5pcs)
 HDW019- Stud, 5/16x2" (4pcs)
 HDW090- Flat Washer 5/16x9/16 (6pcs)
 GSK006- Gasket (2pcs)

1530- Phenolic Spacer (1pc)
 HDW241- Bolt, 5/16-18x1-3/4" (6pcs)
 HDW242- Bolt, 5/16-18x3-3/4" (2pcs)
 GSK085- Gasket (2pcs)

1549- Phenolic spacer (1 pc)
 HDW019- Stud, 5/16x2" (2pcs)
 HDW164- Bolt, 5/16-18x6-1/2" (2pcs)

Revised 2/25/2013

 Join our Facebook page
www.facebook.com/bbkperformance

 Follow us on Twitter
 @bbkperformance

 Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

2

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-003