



INSTRUCTIONS

FOR ALL CHROME ACCESSORIES WITH 3M TAPE

1. INSURE THAT THE SURFACE WHICH THE TRIM IS TO BE APPLIED IS CLEAN, DRY AND FREE OF ALL OIL, GREASE AND WAX. THE APPLICATION SURFACE MUST ALSO BE WARM A MINIMUM OF 50 DEGREES.
2. CHECK FIT THE PEICE ON THE VEHICLE SO WHEN THE SURFACE IS PREPED, YOU WILL KNOW WHERE YOU ARE GOING TO INSTALL IT. DETERMINE THE EXACT LOCATION TO PLACE IT.
3. WASH AREA WITH CLEAN SOAP AND WATER. THEN DRY.
4. REMOVE ALL OILS AND WAX USING ALCOHOL AND A CLEAN CLOTH.
5. REPEAT STEP (4)
6. APPLY ADHESIVE PROMOTER ONLY TO THE SURFACE WHICH THE TRIM WILL COVER LET DRY.
7. APPLY FIRM PRESSURE WITH THE PALM OF YOUR HAND ALL THE WAY AROUND TO INSURE PROPER ADHESION.
8. USE A GOOD QUALITY WAX TO MAINTAIN THE FINISH

**ALL BRITE CHROME PRODUCTS HAVE THE INDUSTRIES ONLY
LIFETIME WARRANTY**

EXCLUDE'S DAMAGES CAUSED BY SHIPPING, MISUSE, OR NEGLECT