



## STEP 1 – PRIOR TO INSTALLATION

- A)** Bushwacker only approves installing the Hood Protector according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) Fit:** Verify the fit of the Hood Protector to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing Trail Armor on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Then follow the paint manufacturer process for TPO plastic.

## Jeep® Trail Armor® Hood Stone Guard

Rear Part #14006

Rev-4 12/3/2013

For complete fitment info visit : [www.bushwacker.com](http://www.bushwacker.com)

### TOOLS FOR EASY INSTALLATION:

- Utility Knife

### LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS

- To claim a warranty, you must provide Proof of Purchase.

## Included in Hardware Kit:

1.



AD1-0010,  
LARGE ALCOHOL  
PREP PAD,  
1 pc

# Hood Protector Installation Procedures:

*IMPORTANT NOTE: Ambient Temperature – During installation: the vehicle, the parts, and the tape need to be between 60° and 110°F for proper adhesion. Vehicle surface must also be wiped with alcohol to remove dirt and grease, which may also affect adhesion. Failure to maintain proper installation temperature and surface preparation may result in the part not functioning correctly.*

## STEP 2:

- A) Peel red vinyl backing from the tape on the Hood Protector.
- B) Align the Hood Protector lip over the edge of the hood as shown in Figure #1 & #2, lining up the ends of the Hood Protector with edge of the hood. The lip of the Hood Protector should wrap around the front edge of the hood. Take care not to exert pressure on the adhesive tape before you have aligned the Hood Protector properly. Gently set into place on the hood.
- C) Apply 30 pounds of pressure per square inch to areas of the parts opposite tape pads to ensure proper tape adhesion.



**Figure #1**  
**Hood Protector Placement**



**Figure #2**  
**Hood Protector lip over edge of hood**