

# **IMPORTANT**

## **1989 - 96 CORVETTE**

Your new Centerforce® pressure plate is precision zero balanced, therefore the outdated procedure of phasing or aligning marks (on the pressure plate and flywheel) is not necessary when the enclosed pressure plate is installed onto a properly balanced flywheel.

Please use the enclosed shouldered pressure plate bolts to fasten the pressure plate to the flywheel in any of the 6 available bolt hole locations.

Torque the pressure bolts to 35-38 ft/lbs.



"NOTE" Centerforce tip sheets are for general reference only. Please refer to your owners manual for vehicle specifications.

# **IMPORTANT**