



Crown Automotive Sales Co., Inc.
Stainless Steel Hood Catch Kit
Replaces P/N: TJHCSS

Kit Contents:

2 – Lower Hood Catches 4 – Small Washers & Nylock Nuts
2 – Upper Hood Catches 2 – Large Washers & Nylock Nuts
2 – Stud Plates

1. Ensure that all components in kit are accounted for.
2. Open hood and remove both upper and lower hood catches from the vehicle. Clean the surface with the proper cleaning agent.
3. Slide the stud plates through the upper hood catches and affix to the hood with the supplied small washers and small nylock nuts.
4. Affix the lower hood catch to the fender so the pins align with their respective holes and affix with the supplied large washers and large nylock nuts.
5. Ensure the upper and lower catches are parallel and that the rubber portion of the catch is not contacting any sharp objects. Adjustment may be necessary to achieve this.

While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. and/or ROUGH TRAIL BY CROWN cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.