

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

| Make    | Model                           |
|---------|---------------------------------|
| Ford    | Explorer with tow package       |
| Lincoln | Navigator with tow package      |
| Mercury | Mountaineer with factory 4-flat |

## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

**S7** - Behind passenger side rear bumper



## CUSTOM WIRING CONNECTOR



## ⚠ WARNING ⚠ ⚡

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

## INSTALLATION / SAFETY INSTRUCTIONS ⓘ

### Step 1

Locate the vehicle taillight wiring harness connector behind the passenger-side rear bumper, as shown on the vehicle location wiring diagram on page 1. The connector will be similar to that on the custom wiring connector. Remove the protective dust cover and clean any debris from the connector.

### Step 2

Insert the custom wiring connector into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

### Step 3

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

### Step 4

Install the provided 4-flat dust cover to help prevent corrosion.

## NOTICE ⓘ ⓘ

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

None