

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Ford	F-150
Ford	F-250
Ford	F-350
Ford	F-250 heavy duty
Ford	F-350 heavy duty

## CUSTOM WIRING HARNESS



## WIRING LOCATION GUIDE

### PICKUP TRUCKS (T)

Representative vehicle shown below

T3 - Behind driver side rear bumper



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

None

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Locate the vehicle taillight wiring harness connectors (A). The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs. **Note:** Lowering of the vehicle spare tire may ease the installation.

## Step 2

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (B).

## Step 3

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

## Step 4

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

