

# 55451

JEEP GRAND CHEROKEE

## WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

5/20/09



## English

1. Open the rear hatch and remove the taillights by removing two T-25 Torx head screws holding each in place.**[A]** Pull out on the taillight housing being sure not to damage the alignment tabs.**[B]** Behind the taillights locate the vehicles taillight wiring harness. The harness will have connectors similar to those on the T-connector.

2. Starting on the drivers side separate the connectors being sure not to damage the locking tabs.**[C]** Insert the T-connector end with the yellow wire in-between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.**[D]**

3. Route the T-connector end with the green wire and the 4-flat wire down through the opening under the taillight. Route the green wire across the backside of the bumper and up through the opening under the passenger side. Repeat step 2 on the passenger side using the green wire.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.**[E]**

5. Adhere the black converter box to the frame of the car behind the taillight using the double-sided tape provided.

6. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



55451