

56023

KIA RONDO
KIA SOUL

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement fileté.

9/17/09



English

1. Open the rear hatch and remove the vehicles taillight assemblies by removing three screws holding each in place.[\[A\]](#)
2. On the drivers side pull out on taillight assembly and locate the vehicles taillight wiring harness. The harness will have connectors similar to those on the T-connectors harness.[\[B\]](#) Separate the connectors being sure not to damage the locking tabs.[\[C\]](#) Insert the T-connector end with the yellow wire in-between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.[\[D\]](#)
3. Route the T-connector end and the 4-flat down through the opening under the taillight.[\[E\]](#) Under the vehicle route the green wire along the backside of the bumper to the passenger side and up through the opening. Repeat step 2 on the passenger side using the green wire.
4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.
5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.
6. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included.
7. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.