



# INSTALLATION / SAFETY INSTRUCTIONS

## Santa Fe & Sorento installation

With factory tow package

### Step 1

Locate the vehicle taillight wiring connector behind the rear tire of the driver side, on the outside frame rail. The connector will be similar to the one on the custom wiring harness.

### Step 2


Remove the protective cap and insert the custom wiring harness into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place (D).

### Step 3

Route the 4-flat to the center of the vehicle by going over the exhaust along the bumper. Avoid any areas that may cut, pinch or melt the wire. Secure any loose wires with the provided cable ties.

### Step 4

Locate a flat clean surface that is out of the path of spray and debris from the rear wheels and road. Adhere the black converter box using the provided double-sided tape. Secure any loose wires with the provided cable ties (E).

 **WARNING:** Failure to mount the box in a protected area can cause loss of warranty, product failure, overheating and potential fire.

### Step 5

To complete the installation, insert the provided 10 AMP fuse into the in-line fuse holder.

## Veracruz Installation

Without factory tow package

### Step 1

Locate the vehicle taillight wiring harness connector near the rear tire on the passenger side, along the frame. The connector will be similar to the one on the custom wiring harness.

### Step 2

Remove the protective cap and insert the custom wiring harness into the vehicle connector (A,B). Make sure the connector is fully inserted with locking tabs in place (C).

