

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Open the vehicle tailgate. Fold down the driver side rear seat to access the interior trim panel (A).

Step 2


On the interior trim panel, remove the access cover labeled 'AUX FUSE' (B).

Step 3

Locate the vehicle trailer wiring harness connector. The connector will be similar to the one on the custom wiring connector (C).

Step 4

Insert the vehicle trailer wiring harness connector into the custom wiring connector. Make sure the connectors are fully inserted with locking tabs in place.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

Step 5

Locate a flat spot behind the removed access panel. Adhere the black converter box using the provided double-sided tape. Secure the remainder of the connector with the provided cable ties.

Step 6

On the driver side, behind the rear bumper fascia, above the tail pipe, locate the grey trailer wiring harness connector. Release connector from its clip and remove the cover from the housing. Insert the 4-flat harness connector. If the cover is not present, be sure the connector and contacts are free of dirt and debris. Make sure that the housings are fully inserted with locking tabs in place (D).

Step 7

When in use, route the 4-flat along the rear bumper to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

Step 8

Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to prevent corrosion.

Step 9

Locate vehicle fuse box in the engine compartment on the driver side (E). Insert tow / trailer fuse provided (F). Check the vehicle owner's manual for location or contact the vehicle manufacturer for more information.

