

56584

BUICK ENCLAVE
BUICK RAINIER
CADILLAC ESCALADE
CHEVY AVALANCHE
CHEVY SILVERADO
CHEVY SUBURBAN
CHEVY TAHOE
CHEVY TRAILBLAZER
CHRYSLER ASPEN
DODGE DURANGO
GMC ACADIA
GMC ENVOY
GMC SIERRA
GMC YUKON
HUMMER H2 & H3
INFINITI QX56
ISUZU ASCENDER
NISSAN PATHFINDER
NISSAN TITAN
OLDSMOBILE BRAVADA
SAAB 9-7X
SATURN OUTLOOK

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

1/18/2011

English

1. Locate the vehicle's factory 7-Way attached on the drivers side near the hitch (A).
2. Separate the vehicles connector from the back side of the factory 7-Way (B). Take care not to damage the locking tabs.
3. Insert the T-Connector end between the separated connectors (C). Make sure the connectors are fully inserted with locking tabs in place.
4. Route the 5-Flat to the center of the vehicle and secure in a safe out of the way location using the cable ties provided.



INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

