



# INSTALLATION INSTRUCTIONS

## 57007 CUSTOM VEHICLE-TO-TRAILER WIRING HARNESS EXTENSION ISOLATION KIT FOR 7-WAY



### TOOLS NEEDED

Drill  
3/8" drill bit

Phillips screwdriver  
Center punch

### WARNING

Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## INSTALLATION

### Step 1

Reference the installation instructions in the 56000 / 56070 5th wheel hitch / gooseneck factory wiring extension kit for installation.

### Step 2

After drilling the hole for the 7-way receptacle, mark the pattern for the mounting holes on the box.

### Step 3

Drill four 3/8" diameter holes.

### Step 4

Insert well nuts into the holes drilled in step 3.

### Step 5

Mount the 7-way in the box using the provided hardware.

### Step 6

Finish the install according to the wiring kit installation instructions.

