11308

03-05 MAZDA 6 & MAZDA 6 SPORT WAGON

10/8/2012

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

			I (o I (o I (o I I I I I I I I I I I I I	
Parts List				
ITEM	QTY	PART NUMBER	DESCRIPTION	FISHWIRE TECHNIQUE
1	1	CM-438-FW	7/16 " FISHWIRE TOOL	INSERT COILED END OF FISHWIRE TOOL THROUGH
2	5	7/16-14 x 1 1/4	CARRIAGE BOLT	HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND OUT THE ACCESS HOLE PASS COILED
3	5	CM-SP2	.250 x .88 x 2.25" SQUARE HOLE SPACER	END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE
4	5	7/16-14	HEX FLANGE NUT	TO KEEP SPACER SEPERATE FROM BOLT AS SHOWN. PULL
		.TERNATE MOUNTING ON SPORT WAGON S		PISHWIRE SPACER AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT / SPACER INSIDE FRAME RAIL. "MOTE SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME"
	WEIGH	<u>IT: 24</u> LBS.	<	
		ONAL: <u>45</u> MINUTES	OF	
		Y): 90 MINUTES	R	
	LL NOT	. —	1. 1.4	
-DRIL	LING RE	EQUIRED	All I	DESIGNED FOR USE WITH
-FISH	WIRE F	ASTENERS		BALLMOUNT #55001 / 45501

INSTALLATION STEPS

- 1) Remove center section of exhaust shield and carpet from inside the trunk for drilling, replace later.
- 2) Fishwire carriage bolts and spacers through ends of bumper beam and out existing holes, as shown.
- 3) Raise hitch into position and secure with flange nuts, finger tighten.
- 4) Using hitch as a template, mark and center punch front mounting holes.
- 5) Lower hitch and drill center punched locations using a 1/2" drill.
- 6) Raise hitch into position over carriage bolts and secure with flnage nuts, as shown.
- 7) Torque all 7/16" fasteners to 70 lb-ft.
- 8) Reinstall heat shield and carpet removed in step one.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.