## 11704

## 89-92 FORD PROBE EXCEPT GT

## 12/10/2012

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.\*\*\*

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.

\*\* FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY\*\*

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

		Parts List		
ITEN	QTY	PART NUMBER	DESCRIPTION	
1	4	7/16-14	HEX FLANGE NUT	
2	2	7/16-14 x 1 1/4	HEX BOLT	
3	2	7_16-14 TAB NUT	HANDLE NUT	
4	2	7/16 LOCK WASHER	HELICAL LOCK WASHER	
5	2	7/16 WASHER	WASHER	U-BOLT 🕟
6	2	7/16-14 x 1.63 x 2.50 C-C	SQ. U-BOLT	(INSTALLATION)
Using wren the hillate and the simple wren Note water	REM techniquer Remonder of a 5/8" of a de up to anger ro dige of a the hang ly rotate ch to res	BER ISOLATOR OVAL DIAGRAM ue can be used if and Exhaust oval Pliers is not available. open end wrench, slide the the rubber isolator, cradiling od as shown. Next place the a pry bar between the wrench er stop or hanger rod. Then the pry bar toward the move the rubber isolator. a spray furchant or soapy hanger rod and the rubber se removal.		PASSENGER SIDI FRAME RAIL  2 4 5 EXISTING STUD
<u>IN</u>	STALL PROFE NOVIC STALL	DRILLED HOI (BOTH SIDE		DESIGNED FOR USE WITH BALLMOUNT #55001 / 45501
	- LOW	ER EXHAUST		

## **INSTALLATION STEPS**

- 1. Under the vehicle, remove (1) 8mm nut from stud on inboard side of each frame rail at rear. Temporarily lower exhaust by removing rear most hangers.
- 2. Notch vertical section of plastic fascia tabs as shown above to clear cross tube.
- 3. Position the hitch on vehicle as shown above. Upper holes in brackets pass over 8mm studs. Reinstall 8mm nuts and secure the hitch in position on the vehicle.
- 4. Drill vehicle frame rails 1/2" diameter through hitch arms (1) places per rail (1 hole per side may exist). Drill car's rear panel 1/2" diameter through lower holes in hitch bracket (1) hole per side.
- 5. Lower hitch and insert U-bolts by placing (1) end into the hole and sliding it in until the inserted end comes out of the adjacent hole. Raise hitch over U-bolts carefully and fasten as shown above. Note: Do not use impact wrench on U-bolts.
- 6. Torque all 8mm hardware to 23 lb.-ft. and all 7/16" hardware to 70 lb.-ft.
- 7. Reinstall exhaust.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.