
12003

96-99 MAZDA MPV

1/31/13

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3500 LBS. TRAILER WEIGHT & 300 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.



INSTALLATION STEPS

- 1) Lower spare tire for ease of installation. (Replace after install)
- 2) Using a 1/2" drill enlarge the (2) holes on the bottom of each frame rail as shown.
- 3) Drill a 1" access hole in the side of the driver side and passenger side frame rail as shown.
- 4) Install 1/2" carriage bolts and large spacers through the end of each frame rail and into enlarged holes as shown.
- 5) Raise hitch into position and secure with flange nuts, finger tighten.
- 6) Fishwire remaining 1/2" carriage bolts and small spacers through access hole, existing hole in frame and hitch, secure with flange nuts.
- 7) Torque all 1/2" fasteners to 110 lb-ft.
- 8) Reinstall spare tire removed in step 1.
 PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS
 ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.