13240

HYUNDAI TUCSON

7/1/2015

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3,500 LBS. TRAILER WEIGHT & 525 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813	J
Parts List	<u> </u>
ITEM QTY PART NUMBER DESCRIPTION WELDNUT CLEANING	
1 8 M10 - 1.25 x 30 HEX BOLT 2 8 3/8" CONICAL TOOTHED WASHER To remove debris from weldnuts	180
in frame, spray lubricant or	
compressed air into hole For heavy debris, use a	
small wire brush	
(Be careful not to damage threads).	
$\bigcap_{i} \bigcap_{j} \bigcap_{i} \bigcap_{j} \bigcap_{j} \bigcap_{i} \bigcap_{j} \bigcap_{j} \bigcap_{i} \bigcap_{j} \bigcap_{j} \bigcap_{i} \bigcap_{j} \bigcap_{j} \bigcap_{i} \bigcap_{j} \bigcap_{j$	
PASSENGER SIDE FRAME RAIL	
PASSENGER SIDE FRAME RAIL	
BE SURE TEETH ON THE CONICAL	
WASHERS ARE AGAINST THE HITCH	1 ()
WASHERS ARE AGAINST THE HITCH	
	/)))
O DRIVED CIDE EDAME DAIL	/ Ā
DRIVER SIDE FRAME RAIL	/ 🖳
	/
EXISTING WELDNUTS	
TOO TOO	DLS REQUIRED
HITCH WEIGHT: 27 LBS.	LO REQUIRED

HITCH WEIGHT: 27 LBS.

INSTALL TIME

PROFESSIONAL: <u>20</u> MINUTES NOVICE (DIY): <u>40</u> MINUTES

INSTALL NOTES:

-NO DRILLING REQUIRED -REMOVE PLASTIC PANELS (IF EQUIPPED) -MAY REQUIRE WELD NUT CLEANING



TOOLS REQUIRED
RATCHET
EXTENSION
17mm SOCKET
TORQUE WRENCH
SHORT #2 PHILLIPS SCREWDRIVER

INSTALLATION STEPS

- 1. If equipped, remove two (2) plastic panels. These are located under the bumper behind the rear tires. Using a screw driver, remove three (3) plastic clips from each panel and pull down to dislodge. Put the panels and fasteners aside for reinstallation later.
- 2. Start by inserting the hitch over the of the exhaust on the passenger side. Rotate the hitch and raise hitch into position. Install four (4) M10-1.25 x 30 with four (4) 3/8" conical tooth washers per side. Be sure the tooth portion of the washer is against the hitch. **Note:** Pull down on the exhaust to ease the installation process.
- 3. Torque all M10 fasteners to 40 ft-lbs.
- 4. Reinstall two plastic panels (if removed in step 1).



PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Scan for more information CURT Manufacturing LLC., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, CURT Manufacturing LLC., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. CURT Manufacturing LLC.'s liability is limited to repair or replacement of products found to be defective, and specifically excluded islability for incidental or consequential loss or damage.