



**Before returning this product
to the store of purchase**

Contact Dee Zee if you experience the following problems:

- Missing Parts
- Installation Problems/Questions
- Warranty Questions

1.800.779.2102

Hours of operation: 8am - 5pm CST, Mon-Friday

Review complete warranty policy and register your product at:

www.deezee.com/warranty.php

Installation Instructions

Side Bar Part #DZ 371697

2004-07 FORD F150 SUPER CAB/2004-07 FORD F150 SUPER CREW

QTY	DESCRIPTION
1	Side Bar, left side
1	Side Bar, right side
1	Hardware Kit

NOTE: Please read this information before installing. Check components received with components listed above.

NO DRILLING REQUIRED for installation of these side bars. To obtain correct installation we recommend you to follow these step by step installation instructions carefully.

Part List

4	1/2-13X2" Hex Head Bolt, Zinc Plated
4	1/2" Flat Washer, Zinc Plated
6	M12 Flat Washer, Zinc Plated
4	1/2" Lock Washer, Zinc Plated
6	M12 Lock Washer, Zinc Plated
8	M8*30 Hex Head Bolt, Zinc Plated
8	M8 Flat Washer, Zinc Plated
4	M8 Flat Washer, Zinc Plated
8	M8 Lock Washer, Zinc Plated
4	M8 Hex Nut, inc Plated
4	M8 Nut-Clip, Zinc Plated
2	M12*45 Bolt Plate, Zinc Plated
6	M12 Hex Nut, Zinc Plated
2	M12*45 Bolt Plate, Zinc Plated

Step one: Locate hardware and verify that all parts are present. Read Instructions completely before installation.

Step two: Attach the front mount brackets DF/PF using (4) 8mm bolt, (2) 8mm nuts (6) flat washers (4) lock washers. Place the 8mm nut clips in the two existing holes on the rocker panel. Attach the brackets to the vehicle as shown in Fig 1. Do not fully tighten at this time.

Step three: Attach the rear mount brackets DR/PR using (4) 8mm bolt, (2) 8mm nuts (6) flat washers and (4) lock washers. Place the 8mm nut clips in the two existing holes on the rocker panel. Attach the brackets to the vehicle as shown in Fig2. Do not fully tighten at this time.

Step four: Install the step bars using (2) 3" plastic rings (2) 1/2"-13x1.75" Hex Head Bolt (2) 1/2" flat washers and (2) 1/2" lock washers. Attach the step bar and rings to the support brackets using the hardware listed in this step. (Fig#1) Fully tighten all hardware at this time. Tighten to 30ft. lbs.

Step five: Repeat steps to complete opposite side of vehicle.



(The images are only for reference. Maybe the actual brackets are different.)

Cleaning Instructions

Black Powder Coat finish: Mild soap, window or glass cleaner may be used. Do not use any type of polish or wax that contains abrasives that could damage the finish.

Stainless Steel finish: Mild soap, window or glass cleaner may be used.