



**Before returning this product
to the store of purchase**

Contact Dee Zee if you experience the following problems:

- Missing Parts
- Installation Problems/Questions
- Warranty Questions

1.800.779.2102

Hours of operation: 8am - 5pm CST, Mon-Friday

Review complete warranty policy and register your product at:

www.deezee.com



Dee Zee Molded Mud Flap Installation Instructions

Congratulations on your purchase of a quality Dee Zee product. Dee Zee is recognized as having the highest quality running boards and accessories on the market today. We have earned this reputation by offering our customers a product they can be proud to place on their vehicles. Dee Zee meets all the criteria of manufacturing a custom-fit product which guarantees it to be the easiest product to install.

Note: Please take time to read all of the instructions before beginning this installation.

Warning! Please check for wiring or other obstructions before drilling any holes into the vehicle. If it is necessary to drill any holes into the vehicle, Dee Zee recommends putting a sealant or rust inhibitor around all holes drilled into body of the vehicle.

Warning! It is the sole responsibility of the vehicle owner to check for tire clearance.

If you should happen to have any questions with this product or you have an installation question, please feel free to call us at:

1-800-779-8222

If you would like to find out more information on Dee Zee's products, please feel free to visit our website at:

WWW.DEEZEE.COM

PART LIST**QTY: 1 Driver & Passenger Side Mudflap****QTY: 2 Hardware Pack****TOOLS REQUIRED****Center Punch / Hammer****Drill****1/8" Drill Bit****Short Phillips Head Screwdriver****3M Protective Film Installation:**

Dee Zee mudflaps are designed to fit snugly into the wheel well. To protect your vehicle, Dee Zee has included a 3M protective film.

- 1) Hold the mudflap up to wheel well to determine 3M protective film placement.
- 2) Thoroughly clean the area where the film is to be installed using 3M brand adhesive cleaner or other petroleum distillate based cleaner.
- 3) Cut the film to the proper shape for your application
- 4) Mix a solution of water and dishwasher detergent into a spray bottle.
- 5) Remove film from the protective liner and spray with the water solution.
- 6) Apply the film to the fender, adhesive side down and spray total area with water solution
- 7) Remove any air bubbles in film using a wet sponge.

Mudflap installation:

- 1) Place the mudflap up to the wheel well and use the existing holes in the mudflap as a guide to center punch and mark the mounting holes on the fender well. Drill 1/8" holes for each location
- 2) Now secure the mudflap to the wheel well using the #8 x 3/4" Phillips head screws. Tighten into place using a short Phillips head screwdriver. On flare side models S-clips may have to be installed behind flare in order for the screws to secure.

