



Toolbox Installation Instructions

- Option 1: **Step 1** – Position toolbox in truck bed across rails and center from side to side.
Step 2 – Drill one 1/8” hole through the center of each end of the box and bed rail where the box rests on the bed rails of the truck.
Step 3 – Fasten toolbox to the bed rails with two #14 sheet metal screws (not included) through the 1/8” holes.
- Option 2: **Step 1** - Position toolbox in truck bed across rails and center from side to side.
Step 2 – Make a mark on the underside of the box where it meets the edge of the bed rail.
Step 3 – Take the box off of the truck and make another mark 5/16” in towards the center of the box.
Step 4 – Drill a 9/32” hole centered from front to rear and on the new mark.
Step 5 – Place toolbox on the truck bed and fasten with two 1/4” J bolts on each side of the truck. The J bolts will hook around the edge of the truck bed rail and the threaded end will go through the 9/32” holes. Fasten with two 1/4” nuts and washers (J bolts, nuts, and washers not included).



Lund International

800-241-7219 • Visit us at lundinternational.com

© 2012 Lund International, Inc. All rights reserved.

Lund® and the Lund® logo are trademarks of Lund International, Inc.

