



PRO COMP SUSPENSION, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

76-86 Jeep CJ Steering Box Brace Part # 55060

Part #	Description	Qty.
	Steering Brace Tube	1 ea
	Steering Box Clamps	2 ea
	7/16"x1 1/2" USS Bolts	4 ea
	7/16" USS Locknuts	2 ea
	7/16" Uss Flat Washers	2 ea
	7/16" Lock Washers	2 ea

INSTRUCTIONS:

- ⇒ Remove rear bolt in the front spring hanger on the passenger side.
- ⇒ Install brace flat plate here using the new hardware for both holes do not tighten. (Hanger bolt and hole 2 1/2" to the rear).
- ⇒ Install clamp halves. Locate brace tube, between the clamp halves.
- ⇒ Torque frame bolts to 60 ft./lbs.
- ⇒ Torque clamp bolt at brace to 60 ft./lbs then the opposite bolt to 60 ft./lbs.

NOTE: Make sure steering linkage will go full left and full right without any binding or interference before driving vehicle.

