



PRO COMP SUSPENSION, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

Part # 55589 Transfer Case Drop Kit

TRANSFER CASE MODIFICATION:

- 1) Place the floor jack under the transfer case skid plate. Loosen the three adjustment mount bolts on the bottom side of the skid plate.
- 2) Remove the skid plate from the frame bolts (three on each side). Lower the assembly enough to place the transfer case spacer tubes (**20-832244**) between the skid plate and the frame. Use the **1/2" x 3-1/2"** hex bolts, with the hardware provided, to re-install the skid plate. As shown in ILLUSTRATION 1.

