



2360 Boswell Road
Chula Vista, CA 91914
Phone 619.216.1444
Fax 619.216.1474
E-Mail tech@explorerprocomp.com

PRO COMP SUSPENSION

Suspension Systems that Work!

Bill Of Materials		
Part #	Description	Qty.
90-6650	HARDWARE PACK: Trans Drop Bracket	1
.100CNNEZ	10mm-1.5 Nylock Nut	2
.100NWHDY	10mm Hardened Flat Washer	2
90-5140	Transmission Drop Bracket: 03-05 (Gas)	1
<i>Or</i>		
90-5143	Transmission Drop Bracket: 06-08 (Gas)	1
<i>Or</i>		
90-5146	Transmission Drop Bracket: 03-05 (5.9L Diesel)	1
<i>Or</i>		
90-5149	Transmission Drop Bracket: 06-08 (5.9L Diesel)	1
<i>Or</i>		
90-5152	Transmission Drop Bracket: 07-08 (6.7L Diesel)	1

**Dodge Transmission
Drop Bracket for
2003 and Newer
Dodge 2500/3500
4WD with Pro Comp
Lift Kits**

INSTALLATION INSTRUCTIONS:

1. Position your vehicle on a smooth, flat, hard surface (i.e. concrete or asphalt). Block the rear tires and set the emergency brake.
2. Carefully place a jack under the transmission bracket and raise it up to relieve the weight on the crossmember and the supports.
3. Remove the **OE** bolts that secure the bracket between the transmission and the rubber crossmember transmission mount.
Note the orientation of the transmission bracket before removal.
4. Install the transmission drop bracket (**90-5140 or 90-5143 or 90-5146 or 90-5149 or 90-5152 depending on application**) to the transmission using the previously removed **OE** bolts. Torque the bolts to 50 ft./lbs.
5. Carefully lower the jack until the transmission drop bracket is resting in place on the transmission rubber mount. Secure using the previously removed **OE** bolts and the supplied **10mm** nuts and washers. Torque the bolts to 50 ft./lbs.
NOTE: You may have to loosen the rubber transmission mount bolts for proper alignment.

⇒ **After 100 miles recheck for proper torque on all newly installed hardware.**

⇒ **Recheck all hardware for tightness after off road use.**