

If you have any comments or concerns,  
please feel free to contact our  
customer service department at:  
Toll-free: 1-800-835-0438  
OR  
Email: info@gofia.com

SEAT COVERS  
BY



FEATURING

**SUPER-GRIP®**

**THE SLIP RESISTANT FASTENING SYSTEM**

INSTALLATION INSTRUCTIONS  
FOR

TR47-6, TR47-61

Oe37-6, Oe37-61

SP87-6, SP87-61

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

**NOTE:** The Super Grip™ buckles are self-locking. For proper usage, see diagram.



**TO INSTALL BACKREST COVERS:**

**NOTE: ON EARLIER MODEL VEHICLES, THE ARMREST WAS ATTACHED TO THE DRIVERS SEAT WITH A METAL POST. THE SEAT COVER WAS ENGINEERED WITH A VELCRO SIDE OPENING TO ACCOMMODATE THE ARMREST. IF YOUR VEHICLE DOES NOT HAVE THE ARMREST ATTACHED IN THIS MANNER, SKIP STEPS 3 AND 5.**

1. move driver seat to most forward position
2. locate backrest cover with Velcro side opening
3. detach Velcro
4. pull cover down firmly
5. attach Velcro under armrest post
6. tuck flap through crevice and attach to Velcro at back
7. move passenger seat to most forward position and repeat steps 4 and 6

**TO INSTALL CUSHION COVERS:**

1. position "60" piece over driver cushion
2. pass front strap under seat and buckle
3. pass side straps around the back of seat and buckle
4. adjust all straps, buckles and Velcro to equalize the tension for a uniform fit
5. position "40" piece over passenger cushion
6. repeat steps 2, 3 and 4

**NOTE: FOR TR47-61 and Oe37-61, AFTER COMPLETING STEP 3 ABOVE, ATTACH THE BACK FLAP WITH VELCRO BEHIND SEAT**

**TO INSTALL ARMREST/CONSOLE COVER (TR47-6, Oe37-6):**

1. open armrest/console lid and slip elastic side of cover over lid
2. tuck corners of cover under lid
3. position adhesive-back Velcro to align with Velcro attached to cover
4. center backrest cover under armrest
5. position adhesive-back Velcro to align with Velcro attached to cover
6. attach Velcro together

**TO INSTALL ARMREST/CONSOLE COVER (TR47-61, Oe37-61):**

1. open armrest/console lid and slip cover over lid
2. center backrest cover under armrest
3. position adhesive-back Velcro to align with Velcro attached to cover
4. attach Velcro together

**WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.**



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone: (204) 475-0515 Toll-Free: 1-800-835-0438  
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com